

Motor Starters & Control Gear Direct On Line Motor Starters



Overload relays must be ordered separately (Page 77). The overload relay setting must not exceed the contactor rating

Overload relays must be ordered separately (Page 77). The overload relay setting must not exceed the contactor rating. Metal Clad DOL's will accept the range of TA8 side mounting auxiliaries (Page 78).

ABS Enclosure 2 Button 110V DOL (IP65)

Part Number	Description	Price	Per
LE1-D123F7	12A 5.5kW 110V AC Coil	£45.68	1
LE1-D253F7	25A 11kW 110V AC Coil	£73.05	1

ABS Enclosure 2 Button 240V DOL (IP65)

Part Number	Description	Price	Per
LE1-D123U7	12A 5.5kW 240V AC Coil	£45.67	1
LE1-D253U7	25A 11kW 240V AC Coil	£73.05	1

ABS Enclosure 2 Button 415V DOL (IP65)

Part Number	Description	Price	Per
LE1-D123N7	12A 5.5kW 415V AC Coil	£45.67	1
LE1-D253N7	25A 11kW 415V AC Coil	£73.05	1

Metal Enclosure 2 Button 240V DOL (IP54)

Part Number	Description	Price	Per
BE1-T1235U7	12A 5.5kW 240V AC Coil	£60.42	1
BE1-T2535U7	25A 11kW 240V AC Coil	£86.94	1
BE1-T3235U7	32A 15KW 240V AC Coil*	£99.75	1

Metal Enclosure 2 Button 415V DOL (IP54)

Part Number	Description	Price	Per
BE1-T1235N7	12A 5.5kW 415V AC Coil	£60.42	1
BE1-T2535N7	25A 11kW 415V AC Coil	£86.94	1
BE1-T3235N7	32A 15KW 415V AC Coil*	£99.75	1

*Use TR2-32353 Overload Relay Only

ABS & Metal Clad DOL Starter Dimensions (mm)

Measurements	ABS	ABS	Metal Clad	Metal Clad
	12A	25A	12A	25 - 32A
a	120	135	116	135
b	140	155	128	147
c	166	185	214	252
d	150	165	134	162
e	88	101	123	156

