


Microwave Movement Sensor

This product is fitted with a microwave movement sensor. Please see below detailed operating instructions.

Technical Specifications:

Operating voltage	220 ~ 240V AC 50/60Hz	
Rated load	400W (Capacitive load) 800W (Resistive load)	
Stand-by power	≤ 0.5W	
Sensitivity	Ceiling mounted height: 3m	100% / 75% / 50% / 25% / 10%
	Ceiling mounted height: 6m*	100% / 75% / 50%
	Wall mounted height: 2m	100% / 75% / 50% / 25% / 10%
Hold-time	5s / 30s / 90s / 3min / 20min / 30min	
Daylight sensor	2Lux / 10Lux / 25Lux / 50Lux / Disable	
Microwave frequency	5.8 GHz ±75MHz	
Transmitting power	1mW Max.	
Detection range	Ceiling mounted height: 3m	3- 6m (radius)
	Wall mounted height: 1.5-2m	12-15m
Detection angle	360° (Ceiling) / 120° (Wall)	
Working temperature	-20°C ~ 60°C	



*50%, 75%, 100% detection sensitivity is workable when installed at 6m mounting height. Only 10%, 25% sensitivity is not able to detect motion signal.

Settings:

<p>1. Sensitivity</p> <p>Sensitivity can be adjusted by selecting the combination on the DIP switches for different applications.</p> <table border="1"> <tr> <td>I - 100%</td> <td>1</td> <td>2</td> <td>3</td> <td>100%</td> </tr> <tr> <td>II - 75%</td> <td>II</td> <td>●</td> <td>●</td> <td>75%</td> </tr> <tr> <td>III - 50%</td> <td>III</td> <td>●</td> <td>○</td> <td>50%</td> </tr> <tr> <td>IV - 25%</td> <td>IV</td> <td>○</td> <td>○</td> <td>25%</td> </tr> <tr> <td>V - 10%</td> <td>V</td> <td>○</td> <td>○</td> <td>10%</td> </tr> </table>	I - 100%	1	2	3	100%	II - 75%	II	●	●	75%	III - 50%	III	●	○	50%	IV - 25%	IV	○	○	25%	V - 10%	V	○	○	10%	<p>2. Hold-time</p> <p>Hold-time refers to the time period that the light remains 100% on if no more movement is detected.</p> <table border="1"> <tr> <td>I - 5s</td> <td>4</td> <td>5</td> <td>6</td> <td>5s</td> </tr> <tr> <td>II - 30s</td> <td>II</td> <td>●</td> <td>●</td> <td>30s</td> </tr> <tr> <td>III - 90s</td> <td>III</td> <td>●</td> <td>○</td> <td>90s</td> </tr> <tr> <td>IV - 3min</td> <td>IV</td> <td>○</td> <td>○</td> <td>3min</td> </tr> <tr> <td>V - 20min</td> <td>V</td> <td>●</td> <td>●</td> <td>20min</td> </tr> <tr> <td>VI - 30min</td> <td>VI</td> <td>○</td> <td>○</td> <td>30min</td> </tr> </table>	I - 5s	4	5	6	5s	II - 30s	II	●	●	30s	III - 90s	III	●	○	90s	IV - 3min	IV	○	○	3min	V - 20min	V	●	●	20min	VI - 30min	VI	○	○	30min	<p>3. Daylight sensor</p> <p>Different daylight threshold can be preset on DIP switches. Light will always turn on upon movement if daylight sensor is disabled.</p> <table border="1"> <tr> <td>I - 2Lux</td> <td>7</td> <td>8</td> <td>9</td> <td>2Lux</td> </tr> <tr> <td>II - 10Lux</td> <td>II</td> <td>●</td> <td>○</td> <td>10Lux</td> </tr> <tr> <td>III - 25Lux</td> <td>III</td> <td>○</td> <td>●</td> <td>25Lux</td> </tr> <tr> <td>IV - 50Lux</td> <td>IV</td> <td>○</td> <td>○</td> <td>50Lux</td> </tr> <tr> <td>V - Disable</td> <td>V</td> <td>○</td> <td>○</td> <td>Disable*</td> </tr> </table> <p>*Disable means the daylight sensor does not work. The sensor will turn on light once motion is detected regardless of ambient light level.</p>	I - 2Lux	7	8	9	2Lux	II - 10Lux	II	●	○	10Lux	III - 25Lux	III	○	●	25Lux	IV - 50Lux	IV	○	○	50Lux	V - Disable	V	○	○	Disable*
I - 100%	1	2	3	100%																																																																														
II - 75%	II	●	●	75%																																																																														
III - 50%	III	●	○	50%																																																																														
IV - 25%	IV	○	○	25%																																																																														
V - 10%	V	○	○	10%																																																																														
I - 5s	4	5	6	5s																																																																														
II - 30s	II	●	●	30s																																																																														
III - 90s	III	●	○	90s																																																																														
IV - 3min	IV	○	○	3min																																																																														
V - 20min	V	●	●	20min																																																																														
VI - 30min	VI	○	○	30min																																																																														
I - 2Lux	7	8	9	2Lux																																																																														
II - 10Lux	II	●	○	10Lux																																																																														
III - 25Lux	III	○	●	25Lux																																																																														
IV - 50Lux	IV	○	○	50Lux																																																																														
V - Disable	V	○	○	Disable*																																																																														

Trouble shooting:

Malfunction Cause Remedy	Cause	Remedy
The light will not come on	Incorrect light-control setting selected	Adjust daylight threshold setting
	Faulty lamp	Replace lamp
	No power supply	Check power to sensor
The lamp is always on	Continuous movement in the detection zone	Check detection area setting
The lamp is on without any identifiable movement	The sensor is not mounted for reliably detecting movement	Securely mount enclosure
	Movement occurred, but not identified by the sensor (Movement behind wall, movement of small object in immediate lamp vicinity etc.)	1. Reduce sensitivity. 2. Check the movement behind walls to avoid facilities such as water pipe, fan, which may mis-trigger the sensor.
The lamp will not work despite movement	Rapid movements are being suppressed to minimize malfunctioning or the detection radius is too small.	Check detection area setting

Care and Safety


We recommend cleaning with a soft dry cloth. Do not use solvents or abrasive cleaners as these could damage the finish.

For your safety, always switch off the power supply before cleaning.

Instruction manual


Hero CCT Microwave

95541



Thank you for purchasing this light fitting. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product. Please retain these instructions for future reference.

Warning

 This light fitting is double insulated and does not require connection to an earth circuit.

Please read these instructions carefully before commencing any work.

This unit must be fitted by a competent and qualified electrician.

Install in accordance with the IEE Wiring regulations and current Building Regulations.

Check the pack and make sure you have all the parts listed.

To prevent electrocution switch off at the mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge.

If you are in any doubt, please consult a qualified electrician.

This light fitting should be connected to a circuit with a 30mA RCD fitted.

If replacing an existing fitting, make a careful note of the connections.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

Technical data

Supply Voltage: 240 V~, 50 Hz

Bulb Type: 9/14/18W LED module (SMD) CCT, 3000/4000/6000K

The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.



Conformity with all relevant EC Directive requirements.



The power supply is Double Insulated and does not require connection to an Earth circuit.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or local store for recycling advice.



This product is not suitable for dimming.



This product is rated at IP65



This product is rated at IK10.

Layout

Plan the desired layout of these fittings carefully, ensuring the cables will reach the distances between each light fitting.

Avoid locating any cables in positions that would cause a hazard. Position cables and junction boxes (not supplied) away from areas where they may be at risk from being cut, trapped or damaged.

The mains supply cable must have a minimum cross section area of 1.0mm².

Cables must be protected using suitable conduit or plastic trunking.

The products can be wall or ceiling mounted. If wall mounting ensure that the power supply is at the bottom.

Individual casings

The following individual casings are available for purchase separately.

95545 : Chrome plain	95548 : Black plain	95551 : Anthracite grey plain
95546 : White eyelid	95549 : Black eyelid	95552 : Anthracite grey eyelid
95547 : White grill	95550 : Black grill	95553 : Anthracite grey grill


Installation

Existing fittings must be completely removed before installation of a new product. Before removing the existing fitting, **carefully note the position of each set of wires.**

Note that the switch is turned off before installation.

The ceiling surface must be flat and smooth to ensure a good fit.

Ensure that the screws and cable entry points are sealed to maintain the IP rating of the product.




The wattage is changeable between 9/14/18W using the wattage switch on the drive before installation.

6000K 4000K 3000K




The colour is changeable between 3000/4000/6000K using the CCT switch on the drive before installation.

- Twist and remove the lamp cover from the product, keep safe for refitting later.
- Turn the clip to loose the LED tray in the rear casing.
- Using the rear casing as a template mark the position to drill out the fixing holes. Take care to avoid damaging any concealed wiring and pipes.
- Fix the rear casing into the position using the installation plugs and screws.
- Pull the cable through the cable entry hole and seal to maintain the IP rating and wire as detailed Wiring Diagram.
- Refit the LED tray back into the rear casing and lock the clip.
- Twist the lamp cover back onto the product and lock in place.
- Replace fuse or circuit breaker and switch on. Your light is now ready for use.



Wiring

Having correctly identified the wiring from your existing light fitting, pull the mains wire through the hole and connect to the quick fit connection block in the following way. No tools are necessary.



Check that...

You have correctly identified the wires.

The connections are tight.

No loose strands have been left out of the connection block.